



Stretch Wing Furniture

STRETCHABLE

Slipcover Fitting Instructions

Start by locating “Center Back of Cover” label which is located at the bottom center.

Drape Slipcover over the furniture, half way down. Use the vertical and horizontal seams as your guidelines.



Lift front portion of Slipcover. Locate “anchor pockets”. Insert anchors on both sides into the arm and back crevices. This will prevent the slipcover from shifting and sliding. Once “anchors” are secured, place the seat cushion back into position and finish draping slipcover all the way down.

Tuck and smooth excess fabric on both sides of wing back furniture towards the back creases where arms and back meet.



Complete finishing touches by adjusting the slipcover length. To adjust the length, **fold in** excess fabric on the bottom of furniture. “**ALL DONE!**”

Easy Fit®
SlipCover